







































































| Original  | Sustituto  |
|---|--|
|  AV    |  AV / Input / RDS |
|  Power |  Power            |
|  Mute  |  Mute / Dimmer    |
|  1     |  1                |
|  2     |  2                |
|  3     |  3                |
|  4     |  4                |
|  5     |  5                |
|  6     |  6                |
|  7    |  7               |
|  8   |  8              |
|  9   |  9              |
|  P+  |  CH+ / Page+    |
|  0   |  0              |
|  V+  |  Vol+           |
|  P-  |  CH- / Page-    |
|  V-  |  Vol-           |

| Original   | Sustituto   |
|--|---|
|  Up/CH+     |  Up                              |
|  Left/Vol-  |  Shift + Left                    |
|  ←          |  Left                            |
|  OK         |  OK                              |
|  Right/Vol+ |  Right                           |
|  Down/CH-   |  Down                            |
|  Menu       |  Menu / Home                     |
|  Exit       |  Exit / Cancel / Clear           |
|  Info       |  Info / Angle                    |
|  EPG       |  Guide / EPG / -/--             |
|  FAV      |  Fav / Marker / PC             |
|  TXT      |  Text / Goto                   |
|  S-T      |  D.Menu / Top                  |
|  Tv/R     |  TV/Radio /                    |
|  Timer    |  Sleep / Timer                 |
|  Edit     |  Setup / OPT /                 |
|  Del      |  Shift + Exit / Cancel / Clear |





|   | Original | Sustituto   | Original | Sustituto |
|---|----------|---|----------|-----------|
|  | Audio    |  Audio / Lang I/II           |          |           |
|  | Red      |  Red / Netflix / Search      |          |           |
|  | Green    |  Green / APP / Repeat        |          |           |
|  | Yellow   |  Yellow / YouTube / Repeat   |          |           |
|  | Blue     |  Blue / Prime Video / Random |          |           |
|   |          |   |          |           |
|   |          |   |          |           |
|   |          |   |          |           |
|   |          |   |          |           |
|   |          |   |          |           |
|   |          |   |          |           |
|   |          |   |          |           |
|   |          |   |          |           |
|   |          |   |          |           |
|   |          |   |          |           |
|   |          |   |          |           |
|   |          |   |          |           |
|   |          |   |          |           |
|   |          |   |          |           |
|   |          |   |          |           |
|   |          |   |          |           |

