







































































Original	Sustituto	Original	Sustituto
	Power		Power
	Source		SRC
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Guide		-/-- / EPG
	Infos		INFO
	Mute		MUTE
	Vol +		VOL +
	Vol -		VOL -
	Format		V-FOR
	Prog +		CH +
	Prog -		CH -
	Red		Red (A)
	Green		Green (B)
	Yellow		Yellow (C)
	Blue		Blue (D)
	Menu		MENU
	Media		MEDIA
	Up		UP
	Down		DOWN
	Right		RIGHT
	Left		LEFT
	OK		OK
	Back		BACK
	Exit		EXIT
	AD		Audio





Original		Sustituto		Original		Sustituto	
	Subtitle		Subt.				
	Text		TEXT				
	Radio		TV/R				
	I<<		First				
	<<		Rewind				
	>>		Fast Forward				
	>>I		Last				
	Rec		Rec				
	Stop		Stop				
	Play		Play				
	Pause		Pause				

