



Original	Sustituto
Standby	Power
Mute	Mute
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Display	Info
Recall	Back
Setup	Menu
EPG	Guide
Source	AV

Original	Sustituto
Audio	Dual
Subtitle	Subt
CH.List	List
FAV	Pre Ch
Up	Up
Down	Down
Right	Right
Left	Left
Ok	Ok
Vol+	Vol +
Vol-	Vol -
Exit/Cancel	Exit
S.Mode	Shift + Dual
P.Mode	Format
CH+/Page+	Ch +
CH-/Page-	Ch -
Red/Goto	Red





Original	Sustituto
Green/A-B	Green
Yellow/Repeat	Yellow
Blue/Angle	Blue
Record	Rec
Rec. List	Smart
TV/Radio	TV/R
Scaler	3D
Play	Play
Pause/Reveal	Pause
Stop/Index	Stop
I<<	I<<
<</Mix	<<
>>I	>>I
>>	>>
Text	Text
S. Page /	D. Menu
Hold/Title	Media

Original	Sustituto
Zoom+/Size	Shift + Ch +
Zoom-	Shift + Ch -
Eject	Eject
Sleep	Sleep

