





































Original	Sustituto
 Power	 Power
 TV/AV	 AV
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Guide
 Recall	 Back
 Vol+	 Vol +
 Vol-	 Vol -

Original	Sustituto
 A1 (no name)	 Shift + 1
 A2 (no name)	 Shift + 2
 B2 (no name)	 Shift + 3
 CH+	 Ch +
 CH-	 Ch -
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Menu	 Menu
 Exit	 Exit
 Picture	 Shift + Format
 Sound	 Shift + Dual
 Sleep	 Sleep
 Display	 Info
 Eject/Aspect	 Format





Original	Sustituto
Eject/Aspect	Eject
FAV	Pre Ch
Play	Play
Pause	Pause
Stop/Nicam/A2	Stop
Goto/Auto	Media
Setup	Options
Title	List
Angle	3D
Audio	Dual
D.Menu/Text	Text
D.Menu/Text	D. Menu
D.Switch/Hold	Smart
Repeat/PgDn	Shift + Text
Repeat/PgDn	Shift + Ch -
Subtitle/PgUp	Subt
Subtitle/PgUp	Shift + Ch +

Original	Sustituto
<</Index	<<
>>/Size	>>
I<</Reveal	I<<
>>I/Subpage	>>I
Red/Program	Red
Red/Program	Shift + Sleep
Green/Zoom	Green
Green/Zoom	Shift + Eject
Yellow/Slow	Yellow
Cyan/A-B	Blue

