























































Original	Sustituto	Original	Sustituto
	Power		Smart Hub
	Source		VOD
	HDMI		VOL +
	1		VOL -
	2		P+
	3		P-
	4		Guide
	5		Menu
	6		Tools
	7		Info
	8		Up
	9		Enter
	0		Down
	TTX/MIX		Right
	PRE-CH		Left
	Mute		Return
	CH List		Exit
			Red
			VOD
			VOL +
			VOL -
			CH +
			CH -
			-/-- / EPG
			MENU
			OPT+
			INFO
			UP
			OK
			DOWN
			RIGHT
			LEFT
			BACK
			EXIT
			Red (A)





Original	Sustituto	Original	Sustituto
Green	Green (B)		
Yellow	Yellow (C)		
Blue	Blue (D)		
Search	Audio		
P.Size	V-FOR		
Status	WIDE		
AD/Subt.	Subt.		
E-Manual	Shift + -/-- / EPG		
History	Shift + P/C / FAV		
<< <<	Rewind		
Pause	Pause		
>> >>	Fast Forward		
Rec	Rec		
Play	Play		
Stop	Stop		

Original	Sustituto

