



Original	Sustituto
Power	Power
[≡_]/Source	AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
-/--	+  Shift + Guide
[≡o]/PRE-CH	Pre Ch
Tv/DTV	TV/R
CH.List	List
D.Menu	D. Menu

Original	Sustituto
Guide	Guide
Vol+	Vol +
Vol-	Vol -
Mute	Mute
P+	Ch +
P-	Ch -
[≡i]/Menu	Menu
[≡x]/Exit	Exit
Up	Up
Down	Down
Right	Right
Left	Left
Enter	Ok
Return	Back
[≡?]/Info	Info
[≡]/[≡]/TTX/MIX	Text
Red	Red



