



























































































|   | Original   | Sustituto   |         | Original  | Sustituto            |
|---|------------|---|---------|---|----------------------|
|    | Standby/On |    | Power   |    | I<<                  |
|    | 1          |    | 1       |    | >>I                  |
|    | 2          |    | 2       |    | Play                 |
|    | 3          |    | 3       |    | Stop                 |
|    | 4          |    | 4       |    | <<                   |
|    | 5          |    | 5       |    | >>                   |
|    | 6          |    | 6       |    | Mute                 |
|    | 7          |    | 7       |    | Prog+                |
|    | 8          |    | 8       |    | Prog-                |
|    | 9          |    | 9       |    | Vol+                 |
|   | 0          |   | 0       |   | Vol-                 |
|  | Tv/DVD     |  | TV/R    |  | Menu                 |
|  | Open/Close |  | Eject   |  | Return               |
|  | DTV/Analog |  | Smart   |  | Exit                 |
|  | Input Sel  |  | AV      |  | Title List/Disc Menu |
|  | Copy       |  | Options |  | Play List/Title Menu |
|  | Pause      |  | Pause   |  | Red                  |





| Original  | Sustituto |   |                 |
|---|-----------|---|-----------------|
|  B           | Green     |  B                     | Green           |
|  C           | Yellow    |  C                     | Yellow          |
|  D           | Blue      |  D                     | Blue            |
|  GUIDE       | Guide     |  GUIDE                 | Guide           |
|  INFO        | Info      |  INFO                  | Info            |
|  SUBTITLE    | Subtitle  |  AD SUBT               | Subt            |
|  TEXT        | Text      |  REPEAT TEXT           | Text            |
|  TV/RADIO    | Tv/Radio  |  PROG SLEEP            | Sleep           |
|  FAV LIST    | FAV List  |  FAV PRE-CH            | Pre Ch          |
|  MARKER      | Marker    |  SHIFT + SETTINGS OPT  | Shift + Options |
|  REC        | Rec       |  REC MODE             | Rec             |
|  AUDIO     | Audio     |  SOUND DUAL          | Dual            |
|  REC MODE  | Rec Mode  |  SHIFT + REC MODE    | Shift + Rec     |
|  REC PAUSE | Rec       |  PICTURE FORMAT      | Format          |
|  REPEAT    | Repeat    |  SHIFT + REPEAT TEXT | Shift + Text    |
|  OK        | OK        |  OK                  | Ok              |
|  Up        | Up        |  Up                  | Up              |

| Original  | Sustituto |  |               |
|---|-----------|--|---------------|
|  Down  | Down      |  Down               | Down          |
|  Right | Right     |  Right              | Right         |
|  Left  | Left      |  Left               | Left          |
|  USB   | USB       |  SHIFT + APP MEDIA  | Shift + Media |
|  TIMER | Timer     |  SHIFT + TIMER AV   | Shift + AV    |
|  HDD   | HDD       |  SHIFT + HOME SMART | Shift + Smart |









































































|  | Original      | Sustituto | Original | Sustituto |
|--|---------------|-----------|----------|-----------|
|  | Input Sel     |           |          | AV        |
|  | 1             |           |          | 1         |
|  | 2             |           |          | 2         |
|  | 3             |           |          | 3         |
|  | 4             |           |          | 4         |
|  | 5             |           |          | 5         |
|  | 6             |           |          | 6         |
|  | 7             |           |          | 7         |
|  | 8             |           |          | 8         |
|  | 9             |           |          | 9         |
|  | 0             |           |          | 0         |
|  | Prog+         |           |          | Ch +      |
|  | Prog-         |           |          | Ch -      |
|  | Standby/On TV |           |          | Power     |
|  | Mute Tv       |           |          | Mute      |
|  | Tv Vol+       |           |          | Vol +     |
|  | Tv Vol-       |           |          | Vol -     |





| Original   | Sustituto   | Original   | Sustituto  |
|--|---|--|--|
|  Standby/On   |  Power     |   <<                    |   <<            |
|  1            |  1         |  >>                     |  >>             |
|  2            |  2         |  Play                   |  Play           |
|  3            |  3         |  Stop                   |  Stop           |
|  4            |  4         |  <<                     |  <<             |
|  5            |  5         |  >>                     |  >>             |
|  6            |  6         |  Prog+                  |  Ch +           |
|  7            |  7         |  Prog-                  |  Ch -           |
|  8            |  8         |  Menu                   |  Menu           |
|  9            |  9         |  Return                 |  Back           |
|  0           |  0        |  Exit                  |  Exit          |
|  Tv/DVD     |  TV/R    |  Title List/Disc Menu |  Media        |
|  Open/Close |  Eject   |  Play List/Title Menu |  Shift + Menu |
|  DTV/Analog |  Smart   |  Red                  |  Red          |
|  Input Sel  |  AV      |  Green                |  Green        |
|  Copy       |  Options |  Yellow               |  Yellow       |
|  Pause      |  Pause   |  Blue                 |  Blue         |





| Original | Sustituto          |
|----------|--------------------|
|          | Guide              |
|          | Info               |
|          | Subt               |
|          | Text               |
|          | D. Menu            |
|          | Pre Ch             |
|          | +  Shift + Options |
|          | Rec                |
|          | Dual               |
|          | +  Shift + Rec     |
|          | Format             |
|          | +  Shift + Text    |
|          | Ok                 |
|          | Up                 |
|          | Down               |
|          | Right              |
|          | Left               |

| Original | Sustituto        |
|----------|------------------|
|          | +  Shift + Media |
|          | +  Shift + AV    |
|          | +  Shift + Smart |

