



| Original | Sustituto |
|-------------------|-----------|
| Power | Power |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 0 | 0 |
| [=+]/-/-- | GUIDE |
| Recall/Auto/Pre-C | PRE Ch |
| Mute | Mute |
| Vol+ | Vol + |
| Vol- | Vol - |
| P+ | Ch + |

| Original | Sustituto |
|----------------|-----------|
| P- | Ch - |
| [=..]/Source | AV |
| [=i]/Menu | Menu |
| (+) | Media |
| [=?]/Info/[+] | Info |
| Exit | Exit |
| Up | Up |
| Right | Right |
| Down | Down |
| Left | Left |
| Enter | Ok |
| TTX/MIX | Text |
| [=o]/Dual I-II | Dual |
| [=◇] | Format |
| [=◇]/Sleep | Sleep |
| Red | Red |
| Green | Green |



