



Original	Sustituto
Power TV	Power
Power STB	+ Shift + Power
Source	AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
TTX/MIX	Text
PRE-CH	Pre Ch
Vol+	Vol +
Vol-	Vol -

Original	Sustituto
Mute	Mute
CH.List	List
P+	Ch +
P-	Ch -
Menu	Menu
Smart Hub	Smart
Guide	Guide
Tools	Options
Info	Info
Back/Return	Back
Exit	Exit
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
Red	Red





Original	Sustituto
Green	Green
Yellow	Yellow
Blue	Blue
	Dual
Status	TV/R
More	3D
E-Manual	D. Menu
Recommend	Format
AD/Subt	Subt
Rec	Rec
	Play

Original	Sustituto

