








































































Original	Sustituto	Original	Sustituto
 Power	 Power	 CH List	 List
 Source	 AV	 P+	 Ch +
 1	 1	 P-	 Ch -
 2	 2	 Menu	 Menu
 3	 3	 Smart Hub	 Smart
 4	 4	 Guide	 Guide
 5	 5	 Tools	 Options
 6	 6	 Info	 Info
 7	 7	 Return	 Back
 8	 8	 Exit	 Exit
 9	 9	 Up	 Up
 0	 0	 Down	 Down
 TTX/MIX	 Text	 Right	 Right
 PRE-CH	 Pre Ch	 Left	 Left
 Vol+	 Vol +	 Enter	 Ok
 Vol-	 Vol -	 Red	 Red
 Mute	 Mute	 Green	 Green





Original	Sustituto	Original	Sustituto
 Yellow	 Yellow		
 Blue	 Blue		
SEARCH Search	SEARCH TV/R		
STATUS Status	APP MEDIA Media		
AD/SUBT. AD/Subt.	AD SUBT Subt		
E-MANUAL E-Manual	E-MANUAL D.MENU D. Menu		
RECOMMEND Recommend	PICTURE FORMAT Format		
 3D	 3D		
 <<	 <<		
 I<<	 I<<		
 Pause	 Pause		
 >>	 >>		
 >>	 >>		
 Rec	REC MODE Rec		
 Play	PLAY MODE Play		
 Stop	 Stop		

Original	Sustituto

