



Original	Sustituto
 Power	 Power
 Open / Close	 Eject
 Dimmer	 Shift + Mute
 BD	 Shift + 1
 Tuner	 Shift + 2
 AUX	 Shift + 3
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Audio	 Dual

Original	Sustituto
 Subtitle	 Subt
 Mo/St / Slow	 Shift + Play
 Pause	 Pause
 <<	 <<
 >>	 >>
 Stop	 Stop
 Play	 Play
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Step	 Shift + Pause
 I<<	 I<<
 >>I	 >>I
 Tuning+ / CH+	 Ch +
 Tuning- / CH-	 Ch -
 Menu	 Menu
 Return	 Back





Original	Sustituto
	Up
	Left
	Ok
	Right
	Down
	Info
	Red
	Exit
	Green
	Yellow
	Blue
	Shift + Menu
	D. Menu
	TV/R
	Shift + TV/R
	Pre Ch
	Format

Original	Sustituto
	Smart
	Media
	Text
	Shift + Text
	Shift + Eject
	Sleep

