




Original	Sustituto
	 Power
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 Audio / Lang I/II
	 0
	 Zoom / Size
	 Subtitle / EQ
	 Fav / Marker / PC
	 AV / Input / RDS
	 Mute / Dimmer

Original	Sustituto
	 Info / Angle
	 Up
	 CH+ / Page+
	 Back / Return
	 Left
	 Vol-
	 OK
	 Right
	 Vol+
	 Menu / Home
	 Text / Goto
	 Down
	 CH- / Page-
	 D.Menu / Top
	 Rec / Rec Mode
	 Red / Netflix / Search
	 Play / Slow



