







Original	Sustituto	Original	Sustituto
Power	Power	?/Help	Options
TV	TV/R	Menu	Menu
Video	Smart	P+	Ch +
↑/CH Scan	Media	P-	Ch -
PRE-CH	Back	Vol+	Vol +
1	1	Vol-	Vol -
2	2	→/ ←/P.STD	Format
3	3	Sleep	Sleep
4	4	Zoom	Eject
5	5	Mute	Mute
6	6	→/ ←/S.STD	D. Menu
7	7	O/I/II/S.Mode	Dual
8	8	Red	Red
9	9	Green	Green
0	0	Yellow	Yellow
---	Guide	Blue	Blue
[+]/[=]/Display	Info	List	





Original		Sustituto		Original		Sustituto	
	[:...]		Subt				
	[≡◇]		AV				
	[≡]		Text				
	[≡◇]		Ok				
	[≡+]		3D				
	[≡x]		Pre Ch				
	[≡o]		Exit				

