



Original	Sustituto
	Power
	Last
	Mute
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	TV/R
	Audio
	Info
	Mode

Original	Sustituto
	Favor
	Menu
	Sub-T
	Exit
	Up
	Down
	Right
	Left
	Ok
	Ch +
	Ch -
	Vol +
	Vol -
	Red
	Green
	Yellow
	Blue









Original	Sustituto	
Power		Power
Last		Pre Ch
Mute		Mute
1		1
2		2
3		3
4		4
5		5
6		6
7		7
8		8
9		9
0		0
TV/R		TV/R
Audio		Dual
Info		Info
Mode		D. Menu

Original	Sustituto	
Favor		Options
Menu		Menu
Sub-T		Subt
Exit		Exit
Up		Up
Down		Down
Right		Right
Left		Left
OK		Ok
CH+		Ch +
CH-		Ch -
Vol+		Vol +
Vol-		Vol -
Red		Red
Green		Green
Yellow		Yellow
Blue		Blue





Original	Sustituto	Original	Sustituto
EPG	GUIDE		
Text	TEXT		







Original	Sustituto	Sustituto
Power		Power
Last		Pre Ch
Mute		Mute
1		1
2		2
3		3
4		4
5		5
6		6
7		7
8		8
9		9
0		0
TV/R		TV/R
Audio		Dual
Info		Info
Mode		D. Menu

Original	Sustituto	Sustituto
Favor		Options
Menu		Menu
Sub-T		Subt
Exit		Exit
Up		Up
Down		Down
Right		Right
Left		Left
OK		Ok
CH+		Ch +
CH-		Ch -
Vol+		Vol +
Vol-		Vol -
Red		Red
Green		Green
Yellow		Yellow
Blue		Blue





Original	Sustituto	Original	Sustituto
EPG	 Guide		
Text	 Text		

