











































Original	Sustituto
 Standby	 Power
 On	 Smart
 A	 Red
 B	 Green
 C	 Yellow
 D	 Blue
 E	 5
 F	 6
 Video	 7
 S Video	 8
 Menu	 Menu
 Eco Mode	 3D
 Return	 Back
 Reset	 Exit
 Enter	 Ok
 Up	 Up
 Down	 Down

Original	Sustituto
 Left	 Left
 Right	 Right
 D.Zoom+	 Ch +
 D.Zoom-	 Ch -
 Muting PIC	 Mute
 Audio	 Dual
 Freeze	 Pause
 APA	 Options
 TWIN	 TV/R
 Vol+	 Vol +
 Vol-	 Vol -
 Focus	 Subt
 Zoom	 Eject
 Aspect	 Format
 Key Stone	 Media
 Pattern	 AV
 Shift	 Text





Original	Sustituto
 Standby	 Power
 On	 Smart
 A	 Red
 B	 Green
 C	 Yellow
 D	 Blue
 E	 5
 F	 6
 Video	 7
 S Video	 8
 Menu	 Menu
 Eco Mode	 3D
 Up	 Up
 Enter	 Ok
 Down	 Down
 Right	 Right
 Left	 Left

Original	Sustituto
 Return	 Back
 Reset	 Exit
 Muting PIC	 Mute
 Audio	 Dual
 Freeze	 Pause
 D.Zoom+	 Ch +
 D.Zoom-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Aspect	 Format
 Zoom	 Eject
 APA	 Options
 TWIN	 TV/R
 Focus	 Subt
 Key Stone	 Media
 Pattern	 AV
 Shift	 Text





Original	Sustituto
Standby	Power
On	Smart
A	Red
B	Green
C	Yellow
D	Blue
E	5
F	6
Video	7
S Video	8
Menu	Menu
Eco Mode	3D
Up	Up
Down	Down
Enter	Ok
Left	Left
Right	Right

Original	Sustituto
Return	Back
Reset	Exit
D.Zoom+	Ch +
D.Zoom-	Ch -
APA	Options
TWIN	TV/R
Freeze	Pause
Muting PIC	Mute
Audio	Dual
Vol+	Vol +
Vol-	Vol -
Focus	Subt
Zoom	Eject
Aspect	Format
Pattern	AV
Shift	Text
Key Stone	Media

