



| Original | Sustituto |
|----------|-------------------|
| | Mute / Dimmer |
| | Picture / Format |
| | Power |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| AV | AV / Input / RDS |
| 0 | 0 |
| SWAP | Back / Return |
| SWAP | D.Menu / Top |
| PC | Fav / Marker / PC |

| Original | Sustituto |
|----------|-----------------------------|
| | TV/Radio / |
| | Menu / Home |
| | Text / Goto |
| | Up |
| | Left |
| | OK |
| | Right |
| | Down |
| | Vol+ |
| | CH+ / Page+ |
| | Vol- |
| | CH- / Page- |
| | Red / Netflix / Search |
| | Green / APP / Repeat |
| | Yellow / YouTube / Repeat |
| | Blue / Prime Video / Random |
| | Info / Angle |





| Original | Sustituto |
|----------|-------------------------------|
| [?] | SMART Smart / List |
| [+] | ZOOM Zoom / Size |
| [◇] | DISPLAY Media Display / Media |
| [≡x] | SURROUND Eject / Surround |
| [:≡] | GUIDE EPG Guide / EPG / -/- |
| [] | SUBTITLE Subtitle / EQ |
| ♪ | TITLE Sound / Title |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Original | Sustituto |
|----------|-----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

