







































































Original		Sustituto		Original		Sustituto	
	Standby		Power		Vol-		Vol -
	Auto		Smart		CH+		Ch +
	Tv/Radio		TV/R		CH-		Ch -
	Mute		Mute		Nicam/A2		Options
	1		1		Aspect		3D
	2		2		Display		Info
	3		3		Up		Up
	4		4		Down		Down
	5		5		Right		Right
	6		6		Left		Left
	7		7		OK		Ok
	8		8		Menu		Menu
	9		9		Exit		Exit
	0		0		Source		AV
	-/--		Shift + Guide		P.Mode		Shift + Format
	Back		Back		S.Mode		Shift + Dual
	Vol+		Vol +		Sleep		Sleep





Original	Sustituto
	Fav
	Fav-
	Fav+
	Hold
	EPG
	Text
	Lang
	Subtitle
	Index
	Reveal
	Subpage
	Media
	Size
	Play
	Pause
	<<
	>>

Original	Sustituto
	Rec
	Stop
	I<<
	>>I
	Red
	Green
	Yellow
	Blue

