



Original	Sustituto	Original	Sustituto
	Power		Power
	Mute		Mute
	V+		Vol +
	V-		Vol -
	AV		AV
	P+		Ch +
	P-		Ch -
	Audio		Dual
	Menu		Menu
	Info		Info
	Exit		Exit
	Up / Channel+		Up
	Down /		Down
	Right / Vol+		Right
	Left / Vol-		Left
	OK		Ok
	Red / RCL		Red
			Green / Pause
			Green / Pause
			Yellow / SUB
			Yellow / SUB
			Blue / Text
			Blue / Text
			FAV
			TV/R
			EPG
			1
			2
			3
			4
			5
			6
			7
			8



