








Original	Sustituto
 Power	 Power
 Source	 AV / Input / RDS
 Picture	 Picture / Format
 Sound	 Sound / Title
 Still	 Pause / Step / Freeze
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 Red	 Red / Netflix / Search
 4	 4
 5	 5
 6	 6
 Green	 Green / APP / Repeat
 7	 7
 8	 8
 9	 9

Original	Sustituto
 Yellow	 Yellow / YouTube / Repeat
 Menu	 Menu / Home
 0	 0
 Exit	 Exit / Cancel / Clear
 Blue	 Blue / Prime Video / Random
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 CH -	 CH- / Page-
 CH +	 CH+ / Page+
 Vol -	 Vol-
 Vol +	 Vol+
 Guide / Size	 Guide / EPG / -/--
 Index / Subtitle	 Subtitle / EQ
 Sleep	 Sleep / Timer





Original	Sustituto
Text	Text / Goto
FAV / Sub Code	Fav / Marker / PC
TV / Reveal	TV/Radio /
Comp / Mix	Display / Media
Language	Audio / Lang I/II
Cancel	Shift + Exit / Cancel / Clear
Info	Info / Angle
Recall	Back / Return
Zoom	Zoom / Size
I / II	Shift + Audio / Lang I/II

Original	Sustituto

