







































































Original	Sustituto	Original	Sustituto
 Power	 Power	 Vol+	 Vol +
 DTV/VCR	 AV	 Vol-	 Vol -
 Info	 Info	 Recall	 Back
 Play	 Play	 Game	 Smart
 Pause	 Pause	 Rec List	 List
 Mute	 Mute	 1	 1
 Exit	 Exit	 2	 2
 Menu	 Menu	 3	 3
 EPG	 Guide	 4	 4
 Favorite	 Pre Ch	 5	 5
 Up	 Up	 6	 6
 Down	 Down	 7	 7
 Right	 Right	 8	 8
 Left	 Left	 9	 9
 OK	 Ok	 0	 0
 CH+	 Ch +	 Tv/Radio	 TV/R
 CH-	 Ch -	 Audio	 Dual





Original		Sustituto		Original		Sustituto	
	Subtitle		Subt				
	Text		Text				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Record		Rec				
	Stop		Stop				
	>>		>>				
	<<		<<				

