







































































Original	Sustituto	Original	Sustituto
 Power	 Power	 0	 0
 Mute	 Mute	 Menu	 Menu
 FAV	 Pre Ch	 Exit	 Exit
 Subtitle	 Subt	 EPG	 Guide
 Info	 Info	 Goto	 AV
 TTX	 Text	 Up	 Up
 Recall	 Back	 Down	 Down
 List	 List	 Right	 Right
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Vol+	 Vol +
 4	 4	 Vol-	 Vol -
 5	 5	 CH+	 Ch +
 6	 6	 CH-	 Ch -
 7	 7	 Pg Up	 Smart
 8	 8	 Pg Dn	 Media
 9	 9	 >>	 >>





	Original	Sustituto	Original	Sustituto
	<<			<<
	>>			>>
	l<<			l<<
	Play			Play
	Pause			Pause
	Stop			Stop
	Rec			Rec
	Lang			Dual
	Timeshift			Options
	Tv/Radio			TV/R
	Repeat			Shift + Text
	Red/Zoom			Red
	Green			Green
	Yellow			Yellow
	Blue/Timer			Blue
	Aspect			3D
	V-Format			Format

