







































































Original	Sustituto	Original	Sustituto
	Power		Power
	Mute		Mute
	Menu		Menu
	Exit		Exit
	Guide		Guide
	Up / P+		Up
	Up / P+		Ch +
	Down / P-		Down
	Down / P-		Ch -
	Left / V-		Left
	Left / V-		Vol -
	OK		Ok
	Right / V+		Right
	Right / V+		Vol +
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Recall		Back
	i		Info
	TV / Radio		TV/R
	SAT		Smart
	FAV		Pre Ch
	Audio		Dual
	Subtitle		Subt
	Text		Text
	Red		Red
	Green		Green





Original	Sustituto	Original	Sustituto
 Yellow	 Yellow		
 Blue	 Blue		
 UHF	 Media		
 Sleep	 Sleep		
 <<	 <<		
 Play	 Play		
 Pause	 Pause		
 >>	 >>		
 Step	 Shift + Pause		
 Stop	 Stop		
 Rec	 Rec		
 Hold	 Shift + Stop		

