



Original	Sustituto
 Power	 Power
 Source	 AV
 Rec	 Rec
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 Lang	 Dual
 <<<	 <<<
 >>>	 >>>
 [≡]..	 Subt
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 1	 1
 2	 2
 3	 3

Original	Sustituto
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Tv	 TV/R
 Recall	 Pre Ch
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Menu	 Menu
 Back	 Back
 Exit	 Exit





Original		Sustituto	
	Q.Menu		D. Menu
	World		Media
	Music/Photo/Video		Smart
	*/o		3D
	*/Q		Eject
	Tv List		List
	Text		Text
	i		Info
	Size		Format
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	P+		Ch +
	P-		Ch -

Original		Sustituto	

