



Original	Sustituto
	Power
	Vol +
	CH+ / Page+
	Vol -
	Mute / Dimmer
	Back / Return
	CH- / Page-
	Exit / Cancel / Clear
	Up
	Menu / Home
	Left
	OK
	Right
	Down
	Text / Got o
	Red / Netfl ix / Search
	Green / APP / Repeat

Original	Sustituto
	Yel l ow / YouT ube / Repeat
	I nf o / Angl e
	Bl ue / Pri me Vi deo / Random
	1
	2
	3
	4
	5
	6
	7
	8
	9
	AV / I nput / RDS
	Set up / OPT /
	<< / Tune-
	Pl ay / Sl ow
	>> / Tune+





Original	Sustituto
Power	Power
Vol +	Vol +
PR+	CH+ / Page+
Vol -	Vol -
Mute	Mute / Dimmer
Back	Back / Return
PR-	CH- / Page-
Exit	Exit / Cancel / Clear
Up	Up
Menu	Menu / Home
Left / Zoom	Left
OK	OK
Right / Zoom+	Right
Down	Down
Text	Text / Goto
Red / [o]	Red / Netflix / Search
Green / Timer / List	Green / APP / Repeat

Original	Sustituto
Yellow	Yellow / YouTube / Repeat
Info	Info / Angle
Blue / []	Blue / Prime Video / Random
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
AV	AV / Input / RDS
SP/LP	Set up / OPT /
<<	<< / Tune-
Play	Play / Slow
>>	>> / Tune+



