







































































Original	Sustituto	Original	Sustituto
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	8		8
	5		5
	6		6
	7		7
	9		9
	0		0
	Source		AV
	Recall		Pre Ch
	Menu		Menu
	Exit		Exit
	[<>]		Format
	→□←		3D
	OK		Ok
	Up		Up
	P+		Ch +
	P-		Ch -
	Down		Down
	Right		Right
	Vol+		Vol +
	Left		Left
	Vol-		Vol -
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	[i+]		Info
	Swap		Sleep
	O)/I/		Dual





Original	Sustituto
[=?]	GUIDE Guide
[▽]	HOME SMART Smart
[■]/[]	SETTINGS OPT Options
[≡i]	APP MEDIA Media
[≡]	REPEAT TEXT Text
[≡o]	AD SUBT Subt
[O]/[≡x]	SEARCH TV/R TV/R
[≡◇]	ZOOM Eject
[≡+]	SHIFT + ECO 3D Shift + 3D

Original	Sustituto

