

































| Original | Sustituto |
|--|--|
|  Power |  Power |
|  Text / Display |  Text |
|  Call / Index |  Info |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Recall |  Pre Ch |
|  Input |  AV |
|  Menu / DVD |  Menu |
|  → [] ← |  3D |

| Original | Sustituto |
|---|--|
|  Aspect |  Format |
|  Exit |  Exit |
|  Up / P+ |  Up |
|  Up / P+ |  Ch + |
|  Down / P- |  Down |
|  Down / P- |  Ch - |
|  Right / Vol + |  Right |
|  Right / Vol + |  Vol + |
|  Left / Vol - |  Left |
|  Left / Vol - |  Vol - |
|  OK |  Ok |
|  Red |  Red |
|  Green |  Green |
|  Yellow |  Yellow |
|  Blue |  Blue |
|  I/II |  Dual |
|  Audio |  Shift + Dual |





| Original | Sustituto | Original | Sustituto |
|--|---|----------|-----------|
|  Power |  Power | | |
|  Menu DVD |  Menu | | |
|  Up |  Up | | |
|  Down |  Down | | |
|  Right |  Right | | |
|  Left |  Left | | |
|  OK |  Ok | | |
|  Pause |  Pause | | |
|  Play |  Play | | |
|  <<< |  <<< | | |
|  >>> |  >>> | | |
|  Open/Close |  Eject | | |
|  Stop |  Stop | | |
|  I<<< |  I<<< | | |
|  >>>I |  >>>I | | |
| | | | |
| | | | |
| | | | |



