


























Original	Sustituto
	 Power
	 Mute / Dimmer
	 Info / Angle
	 Shift + Info / Angle
	 Picture / Format
	 Zoom / Size
	 Smart / List
	 Sound / Title
	 Setup / OPT /
	 Menu / Home
	 1
	 2
	 3
	 4
	 5
	 6
	 7

Original	Sustituto
	 8
	 9
	 Sleep / Timer
	 0
	 Shift + Text /
	 Rec / Rec Mode
	 Stop / Hold
	 Subtitle / EQ
	 Audio / Lang I/II
	 << / FR
	 >> / FF
	 Shift + Yellow / YouTube /
	 Shift + Green / APP /
	 >> / Next
	 Vol+
	 Play / Slow
	 Vol-



