









Original	Sustituto
Standby/On	Power
Open/Close	Eject
TV	TV/R
DV	Smart
AV	AV
Scan	Media
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
ADD/Clear	Exit

Original	Sustituto
Navigation	Pre Ch
Menu	Menu
Setup	Options
Title	List
Up	Up
Down	Down
Select	Ok
Right	Right
Left	Left
Rec/OTR	Rec
Edit	Guide
Timer	Shift + AV
Play	Play
Stop	Stop
Pause/Step	Pause
Mute	Mute
CH+	Ch +





Original	Sustituto
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 I<<	 I<<
 >>I	 >>I
 <<	 <<
 >>	 >>
 Audio	 Dual
 Subtitle	 Subt
 Angle	 Red
 Disc Oper	 Blue
 Return	 Back
 Repeat	 Text
 Zoom	 Shift + Eject
 Slow	 Shift + Play
 Display	 Info
 Prog	 Sleep

Original	Sustituto
 Random	 Yellow
 PS/IS	 Format
 Goto	 3D

