




Original	Sustituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 PgUp	 Ch +
 PgDn	 Ch -
 FAV+	 >>I
 FAV-	 I<<
 Up/CH+	 Up

Original	Sustituto
 Down/CH-	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Menu	 Menu
 Exit	 Exit
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 EPG	 Guide
 Audio	 Dual
 SUB	 Subt
 Zoom	 Eject
 FAV	 Pre Ch





Original	Sustituto	Original	Sustituto
 List	 List		
 Pause	 Pause		
 TXT	 Text		
 Info	 Info		
 Tv/Radio	 TV/R		
 Recall	 Back		

