



Original	Sustituto	Original	Sustituto
	Power		Power
	Mute		Mute / Dimmer
	Movie		TV/Radio /
	Photo		Smart / List
	Music		Sound / Title
	Browser		Display / Media
	Setup		Setup / OPT /
	Info		Info / Angle
	>>/FF		>> / Tune+
	>>I/Next		>>I / Preset+
	Vol+		Vol+
	<</FR		<< / Tune-
	I<</Prev		I<< / Preset-
	Vol-		Vol-
	Home		Menu / Home
	Up		Up
	Return		Back / Return
	Left		Left
	Enter		OK
	Right		Right
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Down		Down
	Stop		Stop / Hold
	Goto		Text / Goto
	Repeat		Green / APP / Repeat
	Audio		Audio / Lang I/II
	Rotate		Fav / Marker / PC
	Zoom		Zoom / Size
	Sub-T		Subtitle / EQ
	16:9		Picture / Format
	AV		AV / Input / RDS
	HDMI		0

