









































Original	Sustituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Browse	 Media
 <X]	 Pre Ch
 Home	 Smart
 Back	 Back
 Mute	 Mute
 Vol+	 Vol +

Original	Sustituto
 Vol-	 Vol -
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 [≡]	 Text
 ↵	 Exit
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Mute Tv	 Shift + Mute
 Vol- Tv	 Shift + Left
 Vol+ Tv	 Shift + Right
 Power Tv	 Shift + Power

