



























































Original	Sustituto
 Power	 Power
 Tv/HMR	 TV/R
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Goto	 Pre Ch
 Mute	 Mute
 I<<	 I<<
 >>I	 >>I
 <<	 <<

Original	Sustituto
 >>	 >>
 Rec	 Rec
 Source	 AV
 Vol+	 Vol +
 Vol-	 Vol -
 →/CM Skip	 Ch +
 ←/INS Replay	 Ch -
 Pause/Step	 Pause
 Stop	 Stop
 Play	 Play
 I>/Slow	 Smart
 Return	 Back
 Home/Guide	 Guide
 Display	 Info
 HDD	 Red
 USB	 Green
 LAN	 Yellow



