

































































Original	Sustituto	Original	Sustituto
	Power		Power
	Prog		Sleep
	Display		Info
	Eject		Eject
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	10+		Guide
	N/P		Ch +
	Subtitle		Subt
	Language		Dual
	Angle		3D
	Setup		Options
	Time		AV
	Title		Blue
	Menu/PBC		Menu
	Up		Up
	Right		Right
	Down		Down
	Left		Left
	Enter		Ok
	Function		Media
	L/R		Ch -
	Step		Format
	Slow		Exit
	Return		Back
	Zoom		Shift + Eject





Original	Sustituto	Original	Sustituto
	Repeat		Text
	A-B		List
	Play		Play
	Pause		Pause
	Stop		Stop
	<<		<<
	>>		>>
	I<<		I<<
	>>I		>>I
	Vol-		Vol -
	Vol+		Vol +
	Mute		Mute
	U/D Scan		Red
	TFT On/Off		Green
	Speaker		Yellow

