
































































| Original | Sustituto | Original | Sustituto |
|-----------|---|--------------|---|
| On/Off |  Power | Progr. |  TV/Radio / |
| Audio Off |  Mute / Dimmer | Top Menu |  D.Menu / Top |
| Play |  Play / Slow | Setup |  Setup / OPT / |
| Pause |  Pause / Step / Freeze | Auto/Track |  Text / Goto |
| Stop |  Stop / Hold | Input Source |  AV / Input / RDS |
| Record |  Rec / Rec Mode | Menu |  Menu / Home |
| Rewind |  << / Tune- | Menu Up |  Up |
| F.Forward |  >> / Tune+ | Info |  Info / Angle |
| Prev. |  I<< / Preset- | Menu Left |  Left |
| Next |  >>I / Preset+ | OK Enter |  OK |
| Title |  Sound / Title | Menu Right |  Right |
| Lang |  Audio / Lang I/II | Play/Back |  Exit / Cancel / Clear |
| Subt. |  Subtitle / EQ | Menu Down |  Down |
| C/CH |  Eject / Surround | Return |  Back / Return |
| Remain |  Picture / Format | Volume+ |  Vol+ |
| Zoom |  Zoom / Size | DVD/TV |  Smart / List |
| Pbc |  Sleep / Timer | Slow Up |  CH+ / Page+ |



| Original | Sustituto | Original | Sustituto |
|--------------|---|----------|--|
| Volume- |  Vol- | Angle |  Shift + Info / Angle |
| Display |  Display / Media | Echo+ |  Shift + Vol+ |
| Slow Down |  CH- / Page- | Echo- |  Shift + Vol- |
| 1 |  1 | Shuffle |  Shift + Blue / Prime |
| 2 |  2 | | |
| 3 |  3 | | |
| 4 |  4 | | |
| 5 |  5 | | |
| 6 |  6 | | |
| 7 |  7 | | |
| 8 |  8 | | |
| 9 |  9 | | |
| +10 |  Guide / EPG / -/-- | | |
| 0 |  0 | | |
| Repeat/1/All |  Green / APP / Repeat | | |
| Rep/A-B |  Yellow / YouTube / Repeat | | |
| Random |  Blue / Prime Video / Random | | |

| Original | Sustituto | Original | Sustituto |
|----------|--|----------|--|
| Angle |  Shift + Info / Angle | Angle |  Shift + Info / Angle |
| Echo+ |  Shift + Vol+ | Echo+ |  Shift + Vol+ |
| Echo- |  Shift + Vol- | Echo- |  Shift + Vol- |
| Shuffle |  Shift + Blue / Prime | Shuffle |  Shift + Blue / Prime |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

