




































































Original	Sustituto
 Power Receiver	 Power
Display/▼	 Ch -
Menu/▲	 Ch +
Return / Repeat	 Text
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 +10	 Guide
 Option	 Options

Original	Sustituto
 Volume +	 Vol +
 Volume -	 Vol -
Tuning +	 >>
Tuning -	 <<
Up	 Up
Left	 Left
 Enter	 Ok
Right	 Right
Down	 Down
 Return / Repeat	 Back
 Info	 Info
 Phono	 Shift + 1
 Tape	 Shift + 2
 CD	 Shift + 3
 Line 1	 Shift + 4
 Line 2	 Shift + 5
 Line 3	 Shift + 6





Original	Sustituto	
Power Receiver		Power
Sleep		Sleep
Info		Info
FM		Smart
AM		Media
Tuning+		Ch +
Tuning-		Ch -
Preset+		Blue
Preset-		Yellow
Vol+		Vol +
Vol-		Vol -
Option		Options
Mute		Mute
Menu/▲		Menu
Display/▼		Shift + Info
Return/Repeat		Back
Up		Up

Original	Sustituto	
Down		Down
Right		Right
Left		Left
Enter		Ok
1		1
2		2
3		3
4		4
5		5
6		6
7		7
8		8
9		9
0		0
+10		Guide
Enter2		Pre Ch
Power Source		Text



