















































Original	Sustituto
	 Power
	 1
	 2
	 3
	 4
	 9
	 Fav / Marker / PC
	 Exit / Cancel / Clear
	 Smart / List
	 Audio / Lang I/II
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 Guide / EPG / -/--
	 Sound / Title
	 Left

Original	Sustituto
	 OK
	 Right
	 CH+ / Page+
	 Vol+
	 CH- / Page-
	 Mute / Dimmer
	 Vol-
	 AV / Input / RDS
	 TV/Radio /
	 Zoom / Size

