





































Original	Sustituto
	Power
	Mute / Dimmer
	Audio / Lang I/II
	Subtitle / EQ
	Text / Goto
	Back / Return
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Info / Angle
	Menu / Home
	Up
	Left
	OK
	Right
	Down

Original	Sustituto
	EPG
	Exit / Cancel / Clear
	Vol+
	Vol-
	Fav / Marker / PC
	Smart / List
	CH+ / Page+
	CH- / Page-
	1
	2
	3
	4
	5
	6
	7
	8
	9



