Mandis shop

Saba TC352

Original	Substitut	Original	Substitut
ON/OFF On/Off	Power		
Channel-	CH -		
Channel+	CH +		
REW << Rew	Rewind		
REW <<Shuttle/Search	First		
FF >>	Fast Forward		
FF Shuttle/Search	Last		
Play	Play		
Stop	Stop		
REC Rec	Rec		
PAUSE Pause	Pause		

https://mandos-a-distancia.es/ca/1009816-83688-comandament-de-substitucio-per-Saba-TC352.html