Mandis shop

JBL WIR1190014301

Original		Substitut	
	Power		Power
SOURCE	Source	TIMER AV	AV
VOL +	Vol+	VOL +	Vol +
VOL −	Vol-	VOL −	Vol -
▶II	Play	PLAY MODE ▶	Play
▶II	Pause	II	Pause
▶I	>I	≫	>>I
I◀	I<	≪	I<<
WIRELESS SURROUND +	Wireless	▲	Up
WIRELESS SURROUND −	Wireless	▼	Down
BASS +	Bass+	CH +	Ch +
BASS −	Bass-	CH −	Ch -
	Mute	MUTE	Mute
SOUND MODE	Sound Mode	SOUND DUAL	Dual
BT	Bluetooth	HOME SMART	Smart
SOUNDSHIFT	Soundshift	AD SUBT	Subt
SHUFFLE	Shuffle	ECO 3D	3D

Original		Substitut	
CALIBRATION	Calibration	SETTINGS OPT	Options
NIGHT MODE	Night Mode	CLEAR EXIT	Exit
DIM DISPLAY	DIM Display	DISPLAY INFO	Info
AUDIO SYNC +	Audio Sync +	▶	Right
AUDIO SYNC −	Audio Sync -	◀	Left

https://mandos-a-distancia.es/ca/JBL/1060833-92459-comandament-de-substitucio-per-JBL-BAR-5.1-WIR1190014301.html