Mandis shop

KODA IP915

Original		Substitut	
	POWER		Power
	MUSIC	SEARCH TV/R	TV/R
menu	MENU	TOP MENU MENU	Menu
enter	ENTER	OK	Ok
	UP		Up
	DOWN		Down
	>>I		>>I
	>>I		Right
	>>I		>>
	I<<		<<
	I<<		I<<
	I<<		Left
	PLAY / PAUSE	PLAY MODE	Play
	PLAY / PAUSE		Pause
mute	MUTE	MUTE	Mute
memory	MEMORY	E-MANUAL D.MENU	D. Menu
stereo mono	STEREO / MONO	SOUND DUAL	Dual

Original		Substitut	
	CLOCK	PROG SLEEP	Sleep
dimmer	DIMMER	REPEAT TEXT	Text
eq reset	EQ RESET	SETTINGS OPT	Options
bass	BASS+	HOME SMART	Smart
bass	BASS-	APP MEDIA	Media
treble	TREBLE+	CH +	Ch +
treble	TREBLE-	CH -	Ch -
	Vol-	VOL -	Vol -
	Vol+	VOL +	Vol +
	Repeat	RETURN BACK	Back

https://mandos-a-distancia.es/ca/KODA/1064357-95041-comandament-de-substitucio-per-KODA-IP915.html