Mandis shop

Sony RM-SGP5

Original	Substitut	Original	Substitut
Power	Power	Play	3D
Clock Timer Set	Smart	Repeat/FM	Text
Clock Timer	Media	Tuner Memory	Rec
MD	Guide	Clear	Exit
Sleep	Sleep	DSG	Menu
Display	Info	Bass+	Up
Play CD	Play	Bass-	Down
Pause CD	Pause	Treble+	Ch +
Stop CD	Stop	Treble-	Ch -
Band Tuner	TV/R		
I<< Preset-	I<<		
>>I/Preset+	>>I		
<> Tape	Red		
<</Tuning-	<<		
>>/Tuning+	>>		
Vol+	Vol +		
Vol-	Vol -		

https://mandos-a-distancia.es/ca/Sony/1060646-6008-comandament-de-substitucio-per-Sony-RM-SGP5-A4433976A.html