Mandis shop

SEAGATE001

Original	Replacement
Power	Power
Home	Smart
Up	Up
Left	Left
OK	Ok
Right	Right
Down	Down
Back	Back
Menu	Menu
i	Info
<<	<<
>>	>>
Play / Pause	Play
Play / Pause	Pause
I<<	I<<
>>I	>>I
Stop	Stop

Original	Replacement
Volume+	Vol +
Volume-	Vol -
Mute	Mute
Zoom+	Ch +
Zoom-	Ch -

https://mandos-a-distancia.es/en/Seagate/1061777-24562-replacement-remote-control-for-Seagate-GOFLEX-CINEMA.html