Mandis shop

LG AKB73615610

Original	Replacement
Power	Power
Back	Back / Return
Home	Menu / Home
Up	Up
Left	Left
OK	OK
Right	Right
Down	Down
Play	Play / Slow
Pause	Pause / Step / Freeze
Info/Menu/123	Info / Angle
Stop	Stop / Hold
I<</<<	<< / Tune-
>>/>>I	>> / Tune+
Red	Red / Netflix / Search
Blue	Blue / Prime Video / Random
Green	Green / APP / Repeat

Original	Replacement
Yellow	Yellow / YouTube / Repeat

https://mandos-a-distancia.es/en/LG/1062193-82856-replacement-remote-control-for-LG-AKB73615610.html