Mandis shop

SARITA

Original	Replacement	Original	Replacement
Power	Power	Down	Down
Mute	Mute / Dimmer	Vol+	Vol+
Play/Pause	Play / Slow	Turn	Turn	Smart / List
<<	<< / Tune-	Vol-	Vol-
>>	>> / Tune+	Repeat	Repeat	Green / APP / Repeat
I<<	I<< / Preset-		
>>I	>>I / Preset+		
Pic	Picture / Format		
Zoom	Zoom / Size		
Input	AV / Input / RDS		
Menu	Menu / Home		
Up	Up		
Info	Info / Angle		
Left	Left		
OK	OK		
Right	Right		
Esc	Exit / Cancel / Clear		

https://mandos-a-distancia.es/en/UNKNOWN/1066369-96362-replacement-remote-control-for-UNKNOWN-REMCON1979.html