Original	Replacement
Power	Power
Mute	Mute / Dimmer
Play	Play / Slow
Pause	Pause / Step / Freeze
Stop	Stop / Hold
Rec	Rec / Rec Mode
<<	<< / Tune-
>>/[≡]	>> / Tune+
I-II/[≡ ≡]	Audio / Lang I/II
Radio	Eject / Surround
[+]	Zoom / Size
[<>] / Timer	Sleep / Timer
Tv	TV/ Radio /
[≡]	Text / Goto
Source/[?]	AV / Input / RDS
Menu	Menu / Home
Up	Up

Original	Replacement
[i +]	Info / Angle
Left	Left
PC/ OK	OK
Right	Right
Down	Down
[X]	Back / Return
Vol +	Vol +
[ ] / Smart	Smart / List
P+	CH+ / Page+
Vol -	Vol -
[♪] / Smart	Display / Media
P-	CH- / Page-
1	1
2	2
3	3
4	4
5	5

Original		Replacement		Original	Replacement
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
ACTIVE CONTROL	[-O-] / Active Control	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
P<P	P<P	PC FAV MARKER	Fav / Marker / PC		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green/[■]	APP REPEAT	Green / APP / Repeat		
	Yellow/[←■]	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
MODE	Prog	SHIFT +	PROGRAM TV/RADIO Shift + TV/Radio / Program		

Original	Replacement
Power	Power
Mute	Mute / Dimmer
Play	Play / Slow
Pause	Pause / Step / Freeze
Stop	Stop / Hold
<<	<< / Tune-
>>	>> / Tune+
I-II / [≡I ≡]	Audio / Lang I/II
[+]	Zoom / Size
[≡]	Text / Goto
Source/[?]	AV / Input / RDS
Menu	Menu / Home
Up	Up
[i+]	Info / Angle
Left	Left
PG/OK	OK
Right	Right

Original	Replacement
Down	Down
Vol +	Vol +
P+	CH+ / Page+
Vol -	Vol -
P-	CH- / Page-
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0

Original	Replacement
Power	Power
Mute	Mute / Dimmer
Play	Play / Slow
Pause	Pause / Step / Freeze
Stop	Stop / Hold
Rec	Rec / Rec Mode
<<	<< / Tune-
>>/[≡]	>> / Tune+
I-II/[≡≡]	Audio / Lang I/II
[<>]/Timer	Picture / Format
[+]	Zoom / Size
Source/[?]	AV / Input / RDS
Menu	Menu / Home
Up	Up
[i+]	Info / Angle
Left	Left
PG/OK	OK

Original	Replacement
Right	Right
Down	Down
Vol +	Vol +
P+	CH+ / Page+
Vol -	Vol -
P-	CH- / Page-
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Red	Red / Netflix / Search

Original	Replacement	Original	Replacement
Green/[■]	APP / REPEAT — Green / APP / Repeat		
Yellow/[←■]	YouTube / REPEAT A-B — Yellow / YouTube / Repeat		
Blue	Prime Video / RANDOM — Blue / Prime Video / Random		