Mandis shop

AUNA 388-BT

Original		Replacement		Original	Replacement
FIND	Find	SEARCH TV/R	TV/R		
INFO	Info	DISPLAY INFO	Info		
REC	REC	REC MODE	Rec		
REP/ INTRO/RAN	Rep/Intro/Ran	OK	Ok		
PROGRAM	Program	PROG SLEEP	Sleep		
▶II	Play/Pause	PLAY MODE ▶	Play		
▶II	Play/Pause	II	Pause		
I◀◀ SKIP/SE	I<<	I◀◀	I<<		
EARCH ▶▶I	Skip/Search	▶▶I	>>I		
■	Stop	■	Stop		
▼ FOLD	Folder Down	CH −	Ch -		
FOLDER ▲	Folder Up	+ CH	Ch +		
SOURCE	Source	TIMER AV	AV		
TS	TS	⏻	Power		
	A2	2	2		
	A1	1	1		

https://mandos-a-distancia.es/en/AUNA/1063107-92928-replacement-remote-control-for-AUNA-388-BT.html