# Mandis shop

BEST002

| Original | Replacement |
|---|---|
| Power | Power |
| Mute | MUTE |
| Setup | VOD |
| Zoom | WIDE |
| Mode | MEDIA |
| Angle | OPT+ |
| Sub-T | Subt. |
| Video | SRC |
| I<< | First |
| >>I | Last |
| << | Rewind |
| >> | Fast Forward |
| Stop | Stop |
| Play | Play |
| Pause | Pause |
| Vol + | VOL + |
| Vol - | VOL - |

| Original | Replacement |
|---|---|
| Up | UP |
| Down | DOWN |
| Right | RIGHT |
| Left | LEFT |
| Enter | OK |
| Display | INFO |
| Audio | Audio |
| Menu | MENU |
| Repeat | TEXT |
| Interval Time | -/-- / EPG |
| Slide Show | P/C / FAV |

https://mandis-distance.com/Best-Buy/10534-8503-replacement-remote-control-for-Best-Buy-Best002.htm