Mandis shop

RC- 47

Original	Replacement
Power	Power
Sleep	Sleep
Stop Phono	Media
< Phono	Smart
Tuner Band	TV/R
P. Call Down	Ch -
P. Call Up	Ch +
I << CD	I <<
>>I CD	>>I
Stop CD	Stop
Play/Pause CD	Play
<< Tape A	<<
>> Tape A	>>
< Tape A	Yellow
> Tape A	Blue
Stop Tape A	Green
<< Tape B	0

Original	Replacement
>> Tape B	Pre Ch
< Tape B	Left
> Tape B	Right
Rec Tape B	Down
Pause Tape B	Ok
Stop Tape B	Up
Presence	Options
Off	Exit
M Call	Subt
Effect	Dual
AUX	AV
Vol +	Vol +
Vol -	Vol -
Mute	Mute

https://mandisdistance.eu/Kenwood-1688-Replacement-remote-control-for-Kenwood-RC-47-110602.htm