Original		Replacement	
	Power		Power
	Ratio		Format
	Simplink		Sleep
	Input		AV
	Tv/Rad		TV/R
	Menu		Menu
	Back		Back
	Exit		Exit
	Mute/Delete		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8

Original		Replacement	
	9		9
	0		0
	Guide		Guide
	FAV/Mark		Pre Ch
	Vol +		Vol +
	Vol -		Vol -
	P+		Ch +
	P-		Ch -
	Net Cast		Smart
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	e/Energy Saving		3D
	List		List
	Q. Menu		D. Menu

Original		Replacement	
Q.VIEW	Q. View	SOUND DUAL	Dual
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	Pause		Pause
	>>		>>
	<<		<<
	Play	PLAY MODE	Play
	Stop		Stop
INFO	Info	DISPLAY INFO	Info
APP/*	APP/*	APP MEDIA	Media
AD	AD	SHIFT + AD SUBT	Shift + Subt
SUBTITLE	Subtitle	AD SUBT	Subt
TEXT	Text	REPEAT TEXT	Text
AV MODE	AV Mode	SHIFT + TIMER AV	Shift + AV
T.OPT	T. Opt.	SETTINGS OPT	Options

Original	Replacement