Mandis shop

REMCON1571

Original		Replacement	
	Power		Power
sleep	Sleep	TIMER SLEEP	Sleep / Timer
iPod	iPod	APP REPEAT	Green / APP / Repeat
aux	AUX	NETFLIX SEARCH	Red / Netflix / Search
am	AM	YouTube REPEAT A-B	Yellow / YouTube / Repeat
fm	FM	Prime Video RANDOM	Blue / Prime Video / Random
I<<	I<<	PRESET-	I<< / Preset-
▶II	Play	SLOW ▶	Play / Slow
▶II	Pause	STEP-FREEZE II	Pause / Step / Freeze
>>I	>>I	PRESET+	>>I / Preset+
	Vol+	+ VOL	Vol+
	Vol-	VOL −	Vol-
	((·))	LIST SMART	Smart / List
	Mute	DIMMER MUTE	Mute / Dimmer
▲	▲		Up
▼	▼		Down
select	Select	OK	OK

Original		Replacement	
menu	Menu	HOME MENU	Menu / Home

https://mandos-a-distancia.es/en/LOGITECH/1065263-90767-replacement-remote-control-for-LOGITECH-REMCON1571.html